



- 1) Flexible rods are made to suit any flag or banner.
- 2) Pockets are sewn down the leading edge (1) vertical and across " the fly " (2) the horizontal.
- 3) The Flexible rod is then inserted and will straighten itself, creating a flag / banner which stands out from the pole at all times, even in zero wind.

How to install the BSSFLEX into \ onto the flag

1. Remove flag \ banner from packaging and identify the two pockets, one on the vertical, one on the horizontal edge.
2. Remove the BSSFLEX from its packaging, being careful so it does not whip itself straight, as injuries may occur. The BSSFLEX will straighten itself in a split second, so please, please be careful when unwrapping, handling or inserting this item.
3. With the flag \ banner held tightly, slip one end (1) of the BSSFLEX into one of the two pockets, and push it all the way down into the pocket.
4. Hold the BSSFLEX in the middle, placing your foot on the inserted end (1) or utilising a second person to hold it tightly, slowly bend the BSSFLEX end (2) towards the other pocket, inserting it as carefully as possible. Again, pushing it all the way to the end of the pocket, prior to releasing it.
5. You should now have a flag \ banner which is supported by the BSSFLEX.
6. Regular monthly checkups on your BSS will keep you aware of fatigue.